



# User Guide

## EASY SILICONE


### 1 Ratio 1:1

Part A 1 : Part B 1



Watch a how to video  
**SCAN HERE**

### 2 How to



#### 1 Prepare

Mold using cardboard or acrylic sheet. Attach your prototype to mold using glue gun. This will prevent your prototype from floating when casting.




#### 2 Measure

1:1 ratio.



#### 3 Mix

For 5-10 minutes and scrape all parts of the container to make sure they are mixed well.




#### 4 Pour

Gently into mold to prevent bubbles from forming.



#### 5 Wait

Wait and leave it dry for 4-6 hours.



#### 6 Unmold

You are all set!

### 3 Level of Hardness : Shore A-10

Smooth surface, resilient and durable.

**Duration** : 30 minutes working time. 45 minutes gel time and fully cure within 3-4 hours at room temperature.

**Applicable with** : Resin, epoxy resin, plaster, candlewax, soap, cement and other castable materials.

## Additional Information

### How to keep EASY SILICONE

Tightly close the container and keep away from sunlight. You can keep for 10-12 months once opened.

### Caution

1. Do not eat or directly inhale.
2. During working, you should wear gloves and mask properly, and wash you hands every time using acetone and followed by soap.
3. In case of contact with eyes, rinse immediately with plenty of water and seek medical advice.
4. Avoid contact with skin. In case of contact with skin, wash immediately with acetone or rubbing alcohol.
5. In case of swallowing the product, do not vomit and get medical help immediately.

## Contact us

LINE @EasyResin

f easyresin

091-767-3305

www.easy-resin.com